


User Manual of MPPT Solar Charge Controller

50A/60A

Maximum PV Voltage (Voc): DC150V



Important safety instructions (Please keep this handbook for future reference. Please read all instructions and precautions in the manual carefully before installation.)

This manual contains all the safety, installation and operation instructions of this series solar charge controller (hereinafter referred to as "controller"):

- Install the controller in a well ventilated place. The controller's case temperature may be very high during operation. Please don't touch the metal shell directly to prevent burns.
- It is recommended to connect fuse or circuit breakers to the input, load and battery terminals to prevent electric shock hazard during use.
- After installation, check all wiring connections are secure, so as to avoid the danger of heat build-up caused by virtual connection.
- If the controller does not display properly when first use, please cut off the fuse or circuit breaker immediately and check whether the wiring connection is correct or not.
- If the solar system needs to connect the inverter, please connect the inverter directly to the battery, instead of the load terminal of the controller.
- Don't disconnect the battery when the controller is charging. Otherwise, it may damage the DC load.

Operation fault codes description

Code	Description	Code	Description	Code	Description
001	Battery over-voltage	010	Battery over-temperature	100	Trigger over-voltage protection
002	PV over-voltage	020	Internal over-temperature	200	Command mode
004	Overcharging	040	PV under-voltage	400	Battery system unrecognized
008	Over-discharging	080	Battery under-voltage		

Table 1

System Voltage and Battery Types

1)The controller identifies the system voltage according to the battery voltage at start-up. And the controller will re-identify the system voltage when power-off and restart. Please ensure the system voltage displayed in controller is consistent with the actual voltage. Otherwise, need to recheck the battery pack voltage.

Note: Please refer to Table 10 for the battery detailed system identification voltage.

2)The controller has set 3 kinds of conventional battery charging parameters (Table 2). To charge other types of batteries, please select "USE", then set up by PC software or APP. The controller can identify 12V/24V/36V/48V ONLY. To charge lithium battery, please select "Lit", then set up on the controller.

Battery type	Constant voltage = C * N (V)	Floating voltage = F * N (V)	1. C = Constant charging parameter. (9 ≤ F < C ≤ 15) 2. F = Floating charging parameter. (9 ≤ F < C ≤ 15) 3. N = Series number of battery. (1 ≤ N ≤ 4) [e.g. N=2, battery system is 24V] 4. Example: If battery system is 48V, then N=4; If battery pack's saturation voltage is 58.4V, then C=58.4/N=14.6V.
Flooded(FLD)	14.6 * N	13.8 * N	
Sealed(SEL)	14.4 * N	13.8 * N	
Gel(GEL)	14.2 * N	13.8 * N	
User (USE)	C * N	F * N	
Li-ion(Lit)	According to the specifications of the selected lithium batteries, charging and protection parameters can be set through the controller panel. Example: Step 1: Enter the setup mode. Step 2: Set the battery type to "Lit". Step 3: Set the parameters of S05-S10. Step 4: Save the setting parameters and exit. Note: Please refer to Table 8.		

Cell Specification
 Nominal Voltage: 3.7V
 Charge Voltage: 4.2V
 Cut-off Voltage: 2.7V

12 cells in series

Reference Settings
 S06: 44.4V
 Nominal Voltage
 S05: 50.4V
 Charge Voltage
 S07: 32.4V
 Under-volt protection

Table 2

Strip Indicator Instruction

The controller has bar indicator light, user can identify the controller current working status according to the color and flash rule of the light.

Strip Indicator Light	Instruction
Yellow Light	Standby state
Red Light	Error warning
Blue Light	Charging state
Green Light	Load indicators

Table 3

1. Characteristics





Figure 1

2. Product List


	Description	Quantity
Product	MPPT controller	1 unit
	Mounting backboard	1 pcs
Installation accessories package	Power cables waterproof connector plug	1 pcs
	RJ45 port waterproof connector plug	2 pcs
	Temperature sensing cable	1 pcs
	M5 screws (for mounting backboard)	2 pcs
	M4 screw (for controller)	4 pcs
	Plastic expansion particles	2 pcs
Information pack	User manual	1 pcs
Optional	RS485-USB cable	1 pcs
	External WIFI communication module	1 unit

Table 4 (If there are any parts missing, please contact dealer.)


3. Installation Instructions




1. Measure and mark the distance 105mm or 85mm on the wall, drill $\phi 6$ mm holes and insert plastic expansion particles and tighten.




2. Align the holes of mounting backboard to the holes in the wall, fix it with M5 screws.



3. Hang the controller to the mounting backboard accordingly.



4. Tighten and fix the controller to the mounting backboard with M4 screws.



5. After the controller is well-installed, connect cables to use.

Remark:

- Above steps of mounting backboard are suitable for general wall installation. If installed on wooden wall, use self-tapping screws to fix it directly.
- Be cautious to the controller installation position, keep 20cm space up and down for good ventilation and heat dissipation.
- The ambient temperature of installation position must be within $-20^{\circ}\text{C} \sim +50^{\circ}\text{C}$, otherwise, the controller may not work properly.

Please keep this handbook in case of need

(Revision data: 201908)

4. Serial connection(string) of solar panels

The **Table 5** is the number(N) of solar panels in series, for reference only.

Voc * N = PV _{input} < DC150V (Table 5)												
System Voltage	Voc<23V		Voc<31V		Voc<34V		Voc<38V		Voc<46V		Voc<62V	
	Max.	Best	Max.	Best	Max.	Best	Max.	Best	Max.	Best	Max.	Best
12V	6	2	4	1	4	1	3	1	3	1	2	1
24V	6	3	4	2	4	2	3	2	3	2	2	1
36V	6	4	4	3	4	3	3	3	3	2	2	1
48V	6	5	4	4	4	3	3	3	3	2	2	2

5. DC Load Output Voltage and Max. Discharge Current

The controller has DC LOAD output function, and its output voltage range is the same as battery pack. For example, if the battery's voltage is 48.6V, the instant DC output voltage is 48.6V, too. It can supply power to DC LOAD continuously if the DC LOAD's current is within the rated range. When the DC LOAD's working current is 100%-120% of rated current for 5 mins, DC LOAD will be OFF. As soon as DC LOAD's working current is over 120% of rated current, the DC LOAD will be OFF immediately.

To restart DC LOAD, user should set Load Type to "ON" or "USE" manually through controller/APP/PC.

6. Instructions for Power cables connecting plug

A 5-wire connector transfer the the power of MPPT controller between solar panels, battery bank and DC loads. After connecting cables into 5-wiring connector, intersect the plug with the controller, the whole wiring connection is completed.



(Figure 2)


(Figure 3)

The **Figure 2** is the disassemble parts of the 5-wiring plug. The **Figure 3** is the corresponding identifier symbol of copper core. Please follow below **Table 6** to correspond to the wire sequence when wiring, and tighten the screws to fix cables.

Please pay attention to the connection method of DC load's positive and negative terminals. The positive pole of DC load is connects to the positive pole of the battery, detail please refers to **Figure 4**.

Terminal Sequence	Symbol	Power Line
L1		PV+
L2		PV-
L3		BAT+
N		BAT-
PE		LOAD-

Table 6



(Figure 4)


7. Communication port description

The communication port of the controller is compatible with RS485-USB communication cable for real-time monitoring by PC software and Wi-Fi module to have remote cloud monitoring by APP.

The communication port is a standard 8 pin RJ45 interface, and the pins are defined as follows(**Table 7**):

PIN	Function
1	RS485-A
2	RS485-B
3	Dry contact
4	Dry contact
5	GND
6	GND
7	+5V(Non-Isolated)
8	+5V(Non-Isolated)

Table 7



(Figure 5)

(Note: The pin definition is applicable to our related products ONLY!)

When the Load output is off due to the triggering protection mechanism, the dry contact output interface will be ON (low impedance). Otherwise, it is OFF (high impedance).

The controller has dual RS485 communication ports. It can be used for communication and parallel connection.


If need to monitor multiple controllers centrally, please set the device address order (1~254) of the controllers accordingly. For example, 5 controllers in parallel connection and monitor centrally, set controllers' address order as 1, 2, 3, 4, 5.

If want to monitor the multiple controllers in Master-Slave communication, set the host controller address to 255. For example, 5 controllers in parallel connection, just need to set the MASTER(host) controller address order as 255.

Tip: For more information, please refer to the official website document.

8. Operation

8.1 LCD display area description



- ① PV information
- ② Battery information
- ③ DC Load information
- ④ Charging navigator
- ⑤ Working status
- ⑥ System information

8.2 Button Operation: (Four buttons: PV, BAT/up, DC/down, S)

Button	Accessible information	In setup mode function
PV	PV voltage/PV current/ PV power/PV total energy	
BAT	Bat voltage/Bat current/Bat power/Bat percentage/ Bat temp/Bat type/Device address	Go up/increase
DC	Load voltage/Load current/Load power/ Load total energy/Load working mode	Go down/decrease

Button	Operational instructions	Setup items
S	<ul style="list-style-type: none"> • Long touch 3S to enter or exit setup mode • Touch the button: -> Selection of settable parameters S01~S14. -> Save parameters before exit 	S01 Bat-Type->USER/SEL/FLD/GEL/LIT S02 Device address S03 Load mode->ON/OFF/USER S04 Bat-temp->°C/°F S05 Charge-Volt->9~60V S06 Nominal-Volt->8.5~58V S07 Under-volt protection voltage S08 Under-volt recovery voltage S09 Over-volt protection voltage S10 Over-volt recovery voltage S11~S12 Realtime set S13~S14 Date set

Table 8


9. Common fault and trouble shooting.

Common Problems	Possible Reasons	Solution
Controller cannot start up, screen can not be on.	Battery positive and negative reverse connected.	Check the wiring, reconnect in right order.
Controller not charging, PV voltage undetectable.	PV Input positive and negative reverse connected.	Check the wiring, reconnect in right order.
Switching from Standby and CC modes in circular manner.	Number of solar panels is too less in series and PV voltage is low.	PV Vmpp voltage must be greater than Vbat. Please refer to the proposed series-parallel scheme(Table 5)
	It may occur in cloudy weather or in early morning and at dusk.	Normal phenomenon.
Controller is on and PV voltage is normal, but not charging.	Unreasonable configuration of solar panels.	Based on sufficient power, please refer to the proposed series-parallel scheme(Table 5)
	The controller can not recognize battery system voltage (The "System" in LCD flashes).	Check whether the battery voltage in LCD is in the range of controller system recognition.
The battery is in a low energy or empty for a long time.	Solar panels quantity are too less to generate enough energy.	Increase solar panels quantity.
	Battery capacity is too small to Store enough energy.	Increase battery capacity.

Table 9

10. Parameters

Model	E4850	E4860		
Product Category	MPPT efficiency	≥ 99.5%		
	Standby consumption	0.5W~1.2W		
	Heat-dissipating method	Natural-Cooling		
		Battery system voltage range	12V system	9VDC~15VDC
			24V system	18VDC~30VDC
36V system			32VDC~40VDC	
48V system	42VDC~60VDC			
Li-ion	8VDC~60VDC(Default), ≤60VDC(Optional activation function)			
Input Characteristics	Max. PV input voltage(Voc)	150VDC		
	Min. Vmpp Voltage	Battery voltage + 2V		
	Start the charge voltage point	Battery voltage + 3V		
	Low input voltage protection point	Battery voltage + 2V		
	Over voltage protection / Recovery point	150VDC / 145VDC		
	Rated PV Power	12V system	650W	780W
		24V system	1300W	1560W
36V system		1950W	2340W	
48V system		2600W	3120W	
Li-ion		630W~2520W	756W~3024W	
Charge Characteristics	Activation for lithium battery	Optional		
	Battery types(Default Gel battery)	Sealed(SEL), Gel(GEL), Flooded(FLD), User-defined(USE), Li-ion(LIT)		
	Rated charge current	50A	60A	
	Temperature compensation	-3mV/°C/2V (default)		
	Charge method	3-stages: CC(Constant Current), CV(Constant Voltage), CF(Floating Charge)		
Output voltage stability accuracy	±0.2V			
LOAD Characteristics	Load voltage	Same as battery voltage.		
	Rated load current	30A		
	Load control mode	On/Off mode, PV voltage control mode, Dual-time control mode, PV + Time control mode		
	Low voltage protection	10.5V (default), 11V (restored), settable		
Setting method	PC software / APP / Controller			
Display & Communication	Display	High-definition LCD segment code backlight display		
	Communication	Dual RJ45 port/ RS485 protocol / PC (via RS485-USB Cable) & APP (via Wi-Fi module) / Centralized monitoring (via parallel connection and RS485-USB cable)		
Other Parameters	Protection	Input & output over-volt / low-voltage protection, reverse polarity protection, over-heating protection, battery shedding protection etc.		
	Operating ambient temperature	-20°C ~ +50°C		
	Storage temperature	-40°C ~ +75°C		
	IP(Ingress protection)	IP67		
	Noise	≤10dB		
Altitude	0~3000m			
Max. Wiring size	28mm²			
Recommended breaker	≥100A			
N. weight (kg) / G. weight (kg)	4.15 / 5.5			
Product size / Packing size(mm)	290×220×88 / 410×328×193			



hexagon bar wrench